



## CG800 e.Glide Trainer

The **CGBOO** e•Glide Trainer was designed for groups/classes or individuals that like to create their own workout scenario in the commercial environment. It will appeal to both runners and cyclists as a cross training modality that is full weight bearing, without the impact.

Other design elements include:

- Patented Direct Drive System produces a unique workout experience
- Infinite resistance adjustments to satisfy every fitness level
- Telemetric Heart Rate for hands free monitoring
- 30 lb. flywheel generates the optimum amount of inertia
- Battery powered console means there is no need for electricity
- Full Commercial Warranty

The unique Patented Direct Drive System, optimally weighted pedal arms, dual-action handlebars,  $2^0$  inverted foot pedals, and stride length combine to create the perfect formula to assure a frictionless stride. This motion creates what we call the "floating" effect. Once your clients reach a certain RPM, they will start to "float" and experience the smoothest possible gait pattern.







The intuitive CG800 console is easy to use and read. Simply set the workout time and get started. The level of effort is manually adjusted by turning the micro-adjustment knob below the console. This moves the rare-earth magnets towards the flywheel to increase resistance. The magnets and a perfectly balanced flywheel work in conjunction to create the smoothest possible feel. Once your clients experience the CGBOO, they will seek it out for both group and individual workouts.

## Equipment Specifications

**CONSOLE** 4-Window LCD, Display, Start/Stop, and Time Adjustment

**HEART RATE** Telemetric (Chest strap sold separately)

RESISTANCE Infinite Levels

DRIVETRAIN Magnetic Resistance w/ Variable Adjustable Knob & Hand Brake

**POWER** 

FLYWHEEL 30 lbs

**PEDALS** Oversized w/ 2-Degree Inversion, Built in Sweat Drains FRAME Heavy-Gauge High-Strength Steel, Zinc Undercoating

w/ Durable Powder-Coat Paint

**DIMENSIONS** 69'' × 24'' × 66''

PRODUCT WEIGHT 230 lbs. MAX USER WEIGHT 450 lbs.

## Warranty Information

**COMMERCIAL** Lifetime: Frame WARRANTY 5 Yrs: Brake & Parts

(Dues Paying Facilities) I Yr: Labor

COMMERCIAL Lifetime: Frame WARRANTY 5 Yrs: Brake & Parts

(Non-Dues Paying Facilities) 2 Yrs: Labor





