



The CS800 Stepper combines the familiar dependent stepping action with an arched step-rail design and impressive 16" maximum step height for an effective lower body workout. The narrow 2" pedal spacing (Q-Factor), large cushioned pedals, and solid handrail design combine to give you an incredibly comfortable and space-efficient cardio unit.

## FEATURES

- Arched step-rail design allows for a more natural stepping motion
- 16 inch maximum step height with 20 levels of resistance satisfy the needs of beginners or advanced exercisers
- Padded handlebars surround the user for a secure and stable workout
- Shielded concave roller wheel system for superior stability and durability
- Ease of use allows users of any fitness level to get an effective workout
- C-Safe Power and Communication capabilities for A/V control
- 2° of inversion at each foot pedal places the user in an anatomically correct position.

# CONSOLE FEATURES

As with any product, a major importance is the user interface. We focused on making everything easily accessible and comfortable: A storage tray for a phone, keys, or an MP3 player, ergonomically friendly pulse grip handles for a more natural hand position, and a Turbo cooling fan to keep your clients cool and encourage them to workout longer.

A quick press of a button and your clients are off on one of the many specialized workouts such as the Fit Test or Constant Power programs. Our large, easy-to-read console gives your clients constant feedback from calories to distance to time.



## EQUIPMENT SPECIFICATIONS

<b>Console</b>	Large Blue-LED Matrix w/ 4 Separate LED Info Windows, 20-Character LED Message Center, LED Heart Rate Bar, Tablet Friendly Reading Rack
<b>Programs</b>	Manual, Hill, Fat Burn, Cardio, Strength, Interval, Fit Test, HR, Constant Power, Custom
<b>Heart Rate</b>	Contact & Telemetric (Chest strap sold separately)
<b>Resistance</b>	20 levels
<b>Step Height</b>	User determined, 16" Maximum Step Height
<b>Power</b>	120 Volts; 15 Amp Circuit recommended
<b>Flywheel System</b>	23 lbs.
<b>Pedals</b>	Oversized and Padded
<b>Frame</b>	Heavy-Gauge High-Strength Steel w/ Durable Powder-Coat Paint
<b>Dimensions</b>	55" x 32" x 63"
<b>Product Weight</b>	175 lbs.
<b>Max User Weight</b>	450 lbs.

## WARRANTY INFORMATION

**Commercial Warranty (Non-Dues Paying Facilities)**  
Lifetime: Frame | 5 Years: Parts & Electronics | 2 Years: Labor



SALES: 800.258.4555



SALES@SPIRITFITNESS.COM



WWW.SPIRITFITNESS.COM