



Designed on the solid CT850 platform, the CT850ENT treadmill incorporates touchscreen technology on an oversized 15.6" ENTERTAINMENT display. TV, web browsing, and music streaming are all made possible within a user interface that is easy to use and adaptable to nearly any facility. The cool running, brushless 4.0 Horse Power AC Drive motor adds to the reliability of the treadmill while providing the torque and smooth continuous power required by the unique needs of its users.

FEATURES

- Large 15.6" touchscreen with TV, web browsing, and music streaming
- 3 different workout display modes give users a variety of workout feedback
- Spacious 22" x 60" workout area to accommodate tall individuals
- Multi-ply Habasit® Commercial Belt for superior belt life
- Maintenance free, hard wax deck system provides hassle free use for thousands of miles
- Large aluminum side rails for stable support, easy cleaning and an elegant design
- Contact and telemetric heart rate options to help keep clients in their effective training zone

OPTION SOLD SEPARATELY



CONSOLE FEATURES

The CT850ENT features a modern 15.6" touchscreen display and electronics package that allows your clients to watch TV, browse the web, and stream their favorite music. Preset programs include a wide variety of popular workouts for the average user while fitness tests, heart rate programs and a custom program are available for more serious users. The fitness test programs include a Gerkin Protocol Fitness Test and 6 Readiness Test Programs (Army, Navy, AirForce, Marines, Coast Guard, PEB).

User comfort was considered with the addition of the Turbo cooling fan, five convenient accessory trays and ergonomically positioned Heart Rate Grips. The CT850ENT also accommodates extended handrails for clients that require extra stability (sold separately).



Watch your favorite TV shows right on the console, control the volume, and switch channels by tapping the virtual buttons on the

DISPLAY

The system provides 3 different viewing modes (Simple, Track, Dashboard) to fine tune your workout experience

INTERNET

Easily access preselected websites and online apps such as YouTube, Facebook, and Twitter through the internet on the

SETTINGS

The console is fully configurable with in-depth console settings. Easily set up the internet connections and modify what websites are available for the user. Also, customize the TV settings, perform diagnostics and maintenance, change default language, update software version, and more.

EQUIPMENT SPECIFICATIONS

Console	15.6" Touchscreen Display, TV Tuner w/Coaxial or HDMI Input, Wi-Fi 802.11 b/g/n or Ethernet, 3.5mm Headphone Jack, Bluetooth 4.0, USB Service Port
Programs	Manual, Interval, 5k, 10k, Calorie, Hill, Fat Burn, Cardio, Gerkin Protocol Fit Test, 6 Readiness Tests (Army, Navy, AirForce, Marines, Coast Guard, PEB), 2 HR, Custom
Heart Rate	Contact & Telemetric (Chest strap sold separately)
Speed / Incline	0.5 - 12 mph / 0 - 15%
Power	120 Volts (NEMA 5-20P Electrical cord); 20 Amp Circuit recommended
Drive Motor	4.0 HP AC Drive with Grade H Insulation
Deck	1" Phenolic, Double-Sided, Wax-Coated
Belt	22" x 60", Habasit® Commercial, Multi-Ply
Rollers	3.0"
Frame	Heavy-Gauge High-Strength Steel w/ Durable Powder-Coat Paint, Aluminum Side Rails
Dimensions	84" x 35" x 57"
Product Weight	406 lbs.
Max User Weight	450 lbs.

Commercial Warranty (Non-Dues Paying Facilities) WARRANTY INFORMATION Lifetime: Tarame | 5 Years | Liber | 2 Years: Labor Console - 3 Years: Parts | 1 Year: Labor





