



# CE900 ELLIPTICAL TRAINER



2-Degree Inversion



Optional TV Bracket (TV not included)

Workout comfort and performance were top of mind when the CE900 Elliptical was developed. From stride length and hand grips to pedal placement and flywheel inertia, this elliptical combines fit and function in one robust machine. With an outstanding warranty, owners can feel secure they've made a solid investment in their users' experience and their bottom line.

## CE900 ELLIPTICAL TRAINER

- 30 lbs. flywheel with a 12:1 pedal to flywheel ratio creates the perfect balance for smooth stride motion at any speed/resistance level
- Extra wide, 12 groove poly-v belt with roller bearing tensioner system to provide smooth feel and long product life
- 21" stride length with exclusive 2-degree pedal inversion to assure a comfortable motion
- Industrial grade 72mm roller bearings assure for long life and added reliability
- Generator system allows the unit to be placed in any location



## CE900 ELLIPTICAL TRAINER

### EQUIPMENT SPECIFICATIONS

<b>Console</b>	premium, ultra-bright blue LED display with built in fan, integrated reading rack with C-safe port and power port for TV remote, heart rate graph bar
<b>Programs</b>	manual, hill, fat burn, HR, HIIT, cardio, interval, watts, strength
<b>Heart Rate</b>	contact and telemetric compatible (chest strap sold separately)
<b>Resistance</b>	40 levels
<b>Stride</b>	21"
<b>Power</b>	self-generating
<b>Drive Train</b>	extra wide, 12 groove poly-v belt with roller bearing and pulley tensioner
<b>Flywheel System</b>	30 lbs. with 12:1 pedal to flywheel ratio
<b>Pedals</b>	oversized with 2-degree inversion
<b>Frame</b>	epoxy hybrid, double powder coated, heavy gauge high strength steel
<b>Dimensions</b>	77" x 32" x 67"
<b>Product Weight</b>	396 lbs.
<b>Max User Weight</b>	450 lbs.

### WARRANTY INFORMATION

**Commercial (All Facilities)** – Lifetime frame, 5 years generator, 3 years parts, and labor